

BSI Part Number	Part Description
-----------------	------------------

### MOUNT SPACERS

1-7/8MS	3/4" x 7/16" x 1-7/8" Mount Spacer
1/2MS	3/4" x 7/16" x 1/2" Mount Spacer
1/4MS	3/4" x 7/16" x 1/4" Mount Spacer
1/8MS	3/4" x 7/16" x 1/8" Mount Spacer
11/16MS	3/4" x 7/16" x 11/16" Mount Spacer
1-1/2MS	3/4" x 7/16" x 1-1/2" Mount Spacer
1-1/4MS	3/4" x 7/16" x 1-1/4" Mount Spacer
1-1/8MS	3/4" x 7/16" x 1-1/8" Mount Spacer
1-11/16MS	3/4" x 7/16" x 1-11/16" Mount Spacer
1-21/32MS	3/4" x 7/16" x 1-21/32" Mount Spacer
1-23/32MS	3/4" x 7/16" x 1-23/32" Mount Spacer
13/16MS	3/4" x 7/16" x 13/16" Mount Spacer
1-3/16MS	3/4" x 7/16" x 1-3/16" Mount Spacer
1-3/4MS	3/4" x 7/16" x 1-3/4" Mount Spacer
1-3/8MS	3/4" x 7/16" x 1-3/8" Mount Spacer
1-5/16MS	3/4" x 7/16" x 1-5/16" Mount Spacer
1-7/16MS	3/4" x 7/16" x 1-7/16" Mount Spacer
17/32MS	3/4" x 7/16" x 17/32" Mount Spacer
1MS	3/4" x 7/16" x 1" Mount Spacer
2-21/32MS	3/4" x 7/16" x 2-21/32" Mount Spacer
23/32MS	3/4" x 7/16" x 23/32" Mount Spacer
2MS	3/4" x 7/16" x 2" Mount Spacer
3/16MS	3/4" x 7/16" x 3/16" Mount Spacer
3/4MS	3/4" x 7/16" x 3/4" Mount Spacer
3/8MS	3/4" x 7/16" x 3/8" Mount Spacer
3/8MS1	3/4" x 13/32" x 3/8" Mount Spacer
3-13/32MS	3/4" x 7/16" x 3-13/32" Mount Spacer
5/16MS	3/4" x 7/16" x 5/16" Mount Spacer
5/32MS	3/4" x 7/16" x 5/32" Mount Spacer
5/8MS	3/4" x 7/16" x 5/8" Mount Spacer
7/16MS	3/4" x 7/16" x 7/16" Mount Spacer
7/8MS	3/4" x 7/16" x 7/8" Mount Spacer